

12 Biggest Drone Mistakes

1. Letting battery drain too low (Flying on Empty)
2. Flying too low in Sport Mode (Stay well above ground level)
3. Not clearing Internal Storage (Clear cache?)
4. Not checking resolution on camera (4K 30 fps?)
5. Not checking firmware (Get Updates)
6. Not setting home point (Return To Home)
7. Not getting shot variety (Same sight gets boring)
8. Not using tools available (Grid lines etc.)
9. Using ND filter too often (Camera lens use)
10. Not inspecting drone after flight (Dirty or damaged?)
11. Flying without knowing rules and regulations (Part 107 License)
12. Not turning on settings (Obstacle avoidance?)

**Designed for the DJI Quads like the Mini 2 or Maverick 3 (Latest version)
Other drone types may vary in their styles or settings use.**