

CRYSTAL SETS TO SIDEBAND

A Guide to Building an Amateur Radio Station

By Frank W. Harris, KØIYE

© Frank W. Harris 2006, Rev 10

(Note: This document is in PDF format. If schematics and drawings appear to have insufficient resolution, increase the display magnification.)

Table of Contents

Chapter 1

THE FASCINATION OF RADIO

Exploring the shortwave bands

Growing up in the Morse code era

The joy of building it yourself

A brief history of radio communication

Henry, Maxwell, Hertz, Tesla, and Marconi.

Fessenden, Edison, Flemming, DeForest and Armstrong

The sinking of the RMS Republic and the birth of ham radio

Ham radio in the last 80 years

Becoming a radio amateur

Chapter 2

HOMEBUILDING AMATEUR RADIO EQUIPMENT

What qualifies as homebuilding?

When homebrewing is not appropriate

Barriers to modern homebuilding –

Time, frequency stability, and lead inductance

Basic electrical knowledge

Magnets and static electricity

Voltage, current, resistance, energy, and power

(Illustrated with drawings of water and mechanical analogies)

Conductors, Insulators, and semiconductors

Capacitors, inductors, transformers, and alternators

Home power distribution, transformers at low and high frequencies

Chapter 3

SETTING UP AN ELECTRONICS WORKSHOP

R&D as recreation

How to build radios (or anything else) in your basement

Persistence, read books, keep a notebook, and work in small increments

Minimum tools needed

The ARRL Amateur Radio Handbook

Soldering irons and small tools

Drills & thread taps

Wood carving gouges for making PC boards

>50 MHz Oscilloscope

Frequency counter

Quality multimeter

Lab power supply

Calculator

Lab notebook

Collection of electronic junk

Parts catalogs

Capacitance meter

Test leads and socket boards

Nice-to-have tools

RF and audio generators, spice software, and spectrum analyzer

Chapter 4

HERTZIAN WAVES IN THE BASEMENT

The nature of radio waves

Mechanical and LC electrical oscillators

Antenna and transmission line theory

Crystal set components

LC tuner

PN junction diode detectors

P-type and N-type semiconductors

Detection of AM signals

Homebuilding the parts for a crystal set

The Jamestown diode

The Caribou headphone

Revisiting Crystal Sets in 2006

Learning to troubleshoot

Selective tuning

Recreating Hertz's radio equipment

3.

- Transmitting and receiving as simply as possible
- The 1880 ten-meter communicator
- Proving that radio waves exist and aren't just capacitive or magnetic coupling
 - Demonstrating standing waves to measure frequency
- Building homebrew transistors
 - Bipolar transistors, PNP and NPN
 - Demonstrating voltage gain
 - The Boulder Rock Radio

Chapter 5

GETTING ON THE AIR

- DECIDING WHAT TO DO FIRST

- How to earn a license
- The rules of the homebuilding game – Whatever makes you happy!
- Picking an HF band
 - Getting acquainted with the HF ham bands, 160 – 10 meters + 6 meters
- Instant high quality HF communications
- VHF/ UHF handheld transceivers
- Building an antenna
 - Dipoles, regular and folded
 - Multi-band dipoles
 - 80 meters when you don't have room for a dipole
 - The curtain rod vertical
 - A multi-band vertical antenna
 - Lightning protection

Chapter 6

BUILDING A QRP HOMEBREW

- A single-band, crystal-controlled, QRP module
- The transmitter mainframe
- HF construction methods
 - Making your own PC boards
 - “Dead Bug” and “Gouged Board” construction
 - Superglue “Island Boards”
 - Coax jumpers
 - Shielded boxes
- The complete QRP crystal-controlled transmitter
- Transistor amplifiers and oscillators
- How an amplifier becomes an oscillator
- Class A and Class C amplifiers
- Stabilizing the operating point, bypass caps, and emitter resistors

4.

Quartz crystals – the key to frequency stability

The 40 meter QRP circuit

Oscillator and buffer

Inductors, RF transformers, and impedance matching

Tapped toroid inductors

How to wind them (and mistakes you might make)

The final amplifier stages for the QRP

Tuned versus broadband - Use both for best results

Bifilar wound, broadband transformers

How to wind them (and how you might screw up)

Ferrite bead RF chokes, expensive RF power transistors, heat sinks, & output connectors

Conquering inductors

Calculating resonance

Calibrating trimmer capacitors

Calculating turns on powdered iron and ferrite toroids

Chebyshev output low pass filters

Keying your QRP

MOSFET power transistors

A “spot switch” for the QRP

Chapter 7

BUILDING A CODE PRACTICE RECEIVER

A simple, direct-conversion receiver

A great first project for a new ham

Excellent sensitivity and good stability

Poor selectivity

Adding 700 Hz audio filtering

High pass and low pass filters

Cascaded bandpass filters increase selectivity

Operational amplifiers

Building with integrated circuits

AM broadcast filter

Getting rid of the image

Chapter 8

POWER SUPPLIES

Line powered power supplies

Power supply safety features

Isolation, 3-conductor cords, fuses, switches, ratings

Supply performance and regulation

- Rectification, ripple, chokes, capacitors, and bleeders
- Zeners, linear regulators, switching regulators
- A QRP regulated power supply
- A battery power supply for the radio shack
- Solar cell charging, low drop-out regulators
- Battery powered shack lighting

Chapter 9

ACCESSORIES FOR THE TRANSMITTER

- A straight key
- An electronic bug
- Building dummy loads
- “T” type antenna coupler
- A low pass filter
- How to stay legal with a homebrew transmitter
- Antenna and power relays
- Homebrew QSL cards

Chapter 10

VARIABLE FREQUENCY OSCILLATORS

- Drift is a big deal today
- Low frequency VFOs drift less than high frequency VFOs
- JFET transistors
- The oscillator circuit
- The buffer, final amplifier, and output filter
- The 50 secrets of avoiding drift
 - JFETs, single-side PC boards, cast metal box, multiple NPO caps, small variable caps, precision voltage regulation, and more
- Vernier tuning
- Varactor tuning elements – advantages and disadvantages
- A precision power supply
- A voltage doubler power supply for battery use
 - Square wave generator with a multivibrator
 - Squaring up the square wave
 - Charge pump, diode/ capacitor voltage doubler
 - Schottky diodes for efficiency
- Temperature compensation methods
 - Positive coefficient capacitive trimmer compensation
 - How to adjust the compensator
 - Thermistor/ varactor temperature compensation

Chapter 11

Building a VFO for the higher bands (PMOs)

Old approaches that no longer work
 Frequency multiplication
 High frequency oscillators
 PreMix Oscillator method of frequency translation
 A VFO-controlled QRP module
 Crystal oscillators are stable, aren't they?
 Crystal oscillator circuits
 Butler oscillators and big crystals
 Mixers, bipolar transistor and dual-gate MOSFET
 Optimum drive requirements
 Direction of tuning, drift error cancellation
 Multistage filters and filter/amplifiers
 The QRP final amplifier stages

Chapter 12

FINAL AMPLIFIERS

The basic features of a modern linear power amplifier
 It looked easier in the Handbook
 Linear "noise mode" operation
 A tuned 50 watt class B amplifier
 Ferrite balun transformers
 An untuned, sort-of-linear, class B, amplifier
 Keying the 50 watt transmitter
 A linear Class AB amplifier, this time for sure
 Single Sideband (SSB) needs a linear
 Biasing without thermal runaway
 Clamp diodes prevent runaway
 Mechanical construction

Chapter 13

BUILDING A HOMEBREW HF RECEIVER

Building a receiver - an unusual adventure
 What's a reasonable goal?
 An "adequate performance" HF communication receiver
 Does it have to be so complicated?

Planning your receiver

Direct conversion versus superhetrodyne

Why not single conversion?

Start with a single-band, single-conversion superhetrodyne

How do modern digital receivers do it?

Receiver construction – build with shielded modules connected by thin coax.

The 80 meter preselector

Reception on 80 meter and 160 meters is aided by a tuned transmatch

The Variable Frequency Oscillator

Mixer magic

Mixers will give you lots of static – and howls and squeals

A practical homebrew mixer made from discrete parts – it's harder than it looks

Dual gate MOSFET mixers

Not all MOSFETS work equally well

A JFET alternative mixer

Crystal ladder filters – essential for CW

All 9.000 MHz crystals aren't equal

Using the BFO oscillator to match crystals

Switch in filters with a rotary switch

The IF amplifier

Lessons learned from a dual-gate IF amplifier

The cascode amplifier strip - variable gain with constant Q

Automatic Gain Control (AGC) - not a luxury

The product detector

Nearly anything works at least a little

The AF amplifier – a vital part of the signal dynamic range

Protecting your ears from strong signals

How Hi-Fi should it be?

Driving a speaker

HF converters for the other ham bands

Crystal oscillators

Bandswitching

Receiver power supplies

Use a linear regulator, not a switching regulator

Chapter 14

OLD-TECH VACUUM TUBE RADIO

How old can radio technology be and still be used on the air today?

Why bother with vacuum tubes?

– Glowing filaments, colored plasmas, and Jules Verne glass envelopes

Power supplies for tubes

- High voltage power supply safety
- The old-tech QRP transmitter
 - Vacuum tube amplifiers
 - The three roles of the triode filament
 - RF sinewave oscillator
 - Quartz crystals
 - Triode and pentode oscillators
- Old-tech voltage regulation – big, crude, expensive, but beautiful
- The travails of triode tubes
 - The oscillator and buffer
 - The final amplifier – triodes chirp
- The transmitter power supply
 - An inadequate supply from a 1935 radio
 - A good power supply made from cheap, modern, boring parts
 - How to check out junk power transformers
 - A complex but adequate supply made from ancient parts
- It works! No one suspects it's old and it's a success on today's 40 meter band
- An old-tech receiver
 - A super regenerative receiver made from ancient tubes
 - The power supply
 - Super-regen on the modern hambands
 - Lots of fun, but not up to modern QRM & QRPs - back to the drawing board!

Chapter 15

THE NOBEL PRIZE FOR SIDEBAND

- It can't be that hard! Want to bet?
- The sideband generator – how it works
 - The 9 MHz oscillator / amplifier
 - The audio amplifier
 - The balanced modulator
 - Building your own crystal ladder filter
 - Decoupling the power supply leads
 - Getting rid of RF feedback - RF filtering for all inputs
- Tuning and testing
- Using the generator for AM modulation and CW
- Moving the 9 MHz SSB signal to a hamband
 - Move the SSB only once!
- No wonder most ham rigs are transceivers
- Moving the 9 MHz signal to the difficult HF hambands
 - Move the VFO first, then mix it with the SSB 9 MHz.
 - Pick your oscillator and VFO frequencies carefully

9.

- Hearing your own VFO in the receiver
- The hardest band – 17 meters
- 40 meters and 12 meters
- Covering the widest band – 10 meters
- A linear sideband QRP, VFO-tuned module
 - All stages must be linear and low distortion
 - All gain stages should be broadband to prevent oscillation
 - Sometimes high pass filter output is needed and not the usual low pass
 - Checking out the generator
- Driving a 50 watt linear amplifier

Chapter 16

ANCIENT MODULATION

- Defining amplitude modulation
- Modulating vacuum tube final amplifiers
 - Plate, screen, & cathode modulation
- A "collector modulator"
- Converting a MOSFET keyer into a modulator
- Generating AM with an SSB balanced modulator
 - Compensating for non-linearity
- Compression by accident
 - You probably don't need to build a compressor
- Ham TV - The old way.
 - Fun with an ancient flying spot scanner TV camera.

In conclusion,

Homebrew ham radio is never complete - when it works perfectly and does all the latest stuff, the hobby is over. Not likely. Long live homebuilding!