

Cut traces to U12 pins 8 & 9

Add jumpers to swap connections to U12 pins 8 & 9

Add R108 and jumper to ground

Cut trace and add R107

Add C21 and jumper to ground

PN: EXC02
PCB Rev. 0
Asy Rev.
Copyright 2006
Paul Alexander
WB9PRA

