

KAM and KAM+ Command Sets

8BITCONV	ASCII	ASCBAUD	AMTOR	ARQBBS	ARQID	ARQTIME
AX25L2V2						
ABAUD	AUTOOCR	AUTOLF	AUTOSTRT	AXDELAY	AXHANG	BEACON
BER						
BITS	BKONDEL	BLT	BREAK	BTEXT	BUDLIST	CONNECT
CANLINE						
CANPAC	CALIBRAT	CD	CHECK	CMDTIME	CMSG	CODE
COMMAND						
CONLIST	CONMODE	CONOK	CONPERM	CONVERS	CPACTIME	CR
CRADD						
CRSUP	CSTAMP	CTEXT	CW	CWAUDIO	CWBAND	CWFARNSW
CWID						
CWIDTEXT	CWPTT	CWSPEED	CWTONE	CWWEIGHT	DISCONNE	DAYTIME
DAYTWEAK						
DAYSTR	DAMA	DAMACHCK	DBLDISC	DELETE	DIDDLE	DIGIPEAT
DISPLAY						
DWAIT	ECHO	ESCAPE	FEC	FLOW	FILTER	FRACK
FREEQUAL						
FSKINV	FULLDUP	GPSHEAD	GPSINIT	GTOR	GTDOWN	GTERRS
GTFUZZY						
GTRIES	GTUP	GMON	GSCAN	HELP	HBAUD	HEADERLN
HID						
HTEXT	ID	INTFACE	INVERT	K	KNTIMER	KNXCON
LAMTOR						
LCOK	LFADD	LFSUP	LLIST	LOWTONES	LT	LTP
LTRACK						
MONITOR	MALL	MARK	MAXFRAME	MAXUSERS	MBEACON	MCON
MCOM						
MHEARD	MISSCHAR	MORSE	MHEADER	MRESP	MRPT	MSTAMP
MXMIT						
MYCALL	MYALIAS	MYAUTOST	MYGATE	MYGROUP	MYGTCALL	MYNODE
MYPBBS						
MYPTCALL	MYREMOTE	MYSELCAL	NAVTEX	NAVCLR	NAVERR	NAVLOG
NAVMSG						
NAVSTA	NDHEARD	NDWILD	NEWMODE	NOMODE	NTEXT	NUCR
NULF						
NUMNODES	PACLEN	PACTIME	PACTOR	PARITY	PASS	PASSALL
PBBS						
PBFORWRD	PBHEADER	PBHOLD	PBKILLFW	PBLIST	PBLO	PBPERSON
PBREVERS						
PERSIST	PHEARD	PID	PMODE	PORT	POSTKEY	PREKEY
PROSIGN						
PTEXT	PTDOWN	PTERRS	PTFECSPD	PTHUFF	PTLISTEN	PTSI
PTRPT						
PTSUM	PTTRIES	PTUP	RTTY	RBAUD	REDISPLA	RELINK
REPHASE						
RESET	RESTORE	RETRY	RING	RNRTIME	RPRINT	RTEXT
STATUS						
SCREENL	SENDPAC	SHIFT	SLOTTIME	SPACE	START	STOP

kam.txt

STREAMSW						
STREAMCA	STREAMEV	SUPLIST	SWP	TRANS	TOR	TRACE
TRFLOW						
TRIES	TXDELAY	TXDFEC	TXFLOW	TXDTOR	UNPROTO	UIDIGI
UIDWAIT						
UIFLOOD	UIGATE	UITRACE	USERS	USOS	VERSION	WEFAX
WTEXT						
XFLOW	XMITECHO	XMITOK	XOFF	XON		