

## ADDENDUM TO DR-570T CROSS BAND REPEATER OPERATION

Your DR-570T is also designed to work as a Cross Band Repeater (XBR). No modification is necessary to use this feature. Here's how it works;

1. Select the frequency for each band.
2. Set the CTCSS Tone frequency, and shift direction if desired.  
(Note: The incoming CTCSS Tone will not be passed through the radio.)
3. Set both squelch control knobs to the threshold.  
(Turn the knob clockwise slowly until noise goes off.)
4. Slide the XBR switch on the top cover to the "REPEATER" mode.
5. Now your DR-570T is working as a Cross Band Repeater. When an incoming signal is received on either band, it will be re-transmitted to the other band.

Note: A long transmission may cause various problems. We suggest that you keep our recommended duty cycle of 1:3 (1 min. TX, 3 min. RX) whenever possible, and use low power for XBR whenever possible.