


UP & DOWN SWITCH



PIN No.

- #4
- #8
- #1
- #7
- #5
- #2
- #3

TO MIC PLUG

# MIC CABLE WIRING

## FOR

ALR-22T, ALR-22HT, ALR-72T, ALD-24T  
 DR-110T, DR-410T, DR-510T, DR-570T

NUMBER	8 conductor cable	7 conductor cable
1	YELLOW	YELLOW
2	RED	ORANGE
3	PURPLE	WHITE
4	GREEN	GREEN
5	WHITE	RED
6	NOT USED (ORANGE)	NOT USED
7	SCHIELD (BLACK)	SCHIELD (BLACK)
8	GRAY	GRAY