



View from the bottom side

A = start of winding, nearest the bottom of coil can

E = finish of winding, nearest top of coil can

(see Neosid data sheet for Type 7.1E inductor)

Neosid Type 7.1 E Inductor Identification
e.g. for 511732 170 nH inductor