




Enable TX PL tone only on active CAS from receiver

Drop PL encode output tone with no RX signal

Adjust R1 & R2 for desired mute level

GE Master II

PL ENCODE MUTE CIRCUIT

R. Hogan W4XE

Rev 1.0

12/13/2005

Page 1