


Accurate indication of "dB" in Transmission Mode using IGminiVNA
YO4HFU



- During VNA calibration, connect DUT with DET (loop)
- Open the switch and adjust 50K resistor for "870" indication
- Close the switch and adjust 500K resistor for "790" indication