

Icom IC-7000 Frequently Asked Questions (FAQ)

This guide was created to answer the most commonly asked questions about the Icom IC-7000. The goal is two-fold:

- 1) Condense the discussions found in the Yahoo group to the raw information providing a definitive source for the FAQ reader
- 2) Remove these recurring questions from the group to improve the “signal to noise ratio”

Instructions for updating, correcting and adding information are located at the end of this FAQ.

IC-7000 Unique Features

- The IC-7000 was the smallest multimode radio available at its introduction (and the time of this writing)
- It was the first truly mobile radio to feature IF-DSP (customizable filters – nothing to buy)
- Filter width adjustable by mode with “sharp” and “soft” shape factors
- Dual ADI Blackfin DSP Processors - feature set similar to the IC-7800, IC-756 Pro III
- ACG loop performance controlled by DSP
- Auto notch plus dual manual notch filters for up to 70 dB of attenuation
- Noise blanker features adjustable pulse width and depth of cut
- Internal RTTY decode and dual peak RTTY filter
- High stability crystal oscillator is standard
- Voice synthesizer standard
- VFO knob includes a working “spinner”
- The VFO knob tension is adjustable from free to tight and detented – great for mobile operation!
- Microphone and external speaker jacks on both the head and body
- Color composite video output available at all times to support a larger monitor
- Multifunction display shows complete receiver status, S-meter/power output, ALC, compression, SWR and final temperature on a single screen
- Semi-real-time spectral display 25-500kHz wide with peak hold and SWR sweep meter
- VHF NTSC TV reception with internal modification
- Many functions, including band stack registers, direct frequency entry, mode, filters and speech synthesizer available directly via the microphone (no menu navigation required)
- Two programmable function keys on microphone for most used functions
- CW/Voice memory keyer with 4 memories each and internal recorder feature
- CW/voice keyer directly accessible with simple box described in manual
- Thermostatically controlled fan
- Less receive standby current draw than the IC-706MKIIG
- Remotely mountable head
- 6-pin data jack and 13-pin accessory jack
- Customizable opening message

User Measured Specifications

Power output

The IC-7000 maximum output power drops as voltage drops. This behavior is consistent with other radios as shown by the Yaesu FT-450 results below.

The band tested below was not specified.

VOLTAGE	RECEIVE CURRENT	TRANSMIT CURRENT	POWER OUTPUT
13.84	2.0	17	93
13.49	2.0	17	92
13.01	2.0	17.5	92
12.50	2.0	17.5	90
12.02	2.0	16.0	80
11.50	2.0	14.5	70
11.01	2.0	14.0	60
10.50	2.0	12.5	50
10.00	2.0	11.5	40
9.50	2.0	XMIT FAILED	

Voltage measured at power supply. Cables supplied by Icom. Power out as indicated in CW mode on attached tuner into a dummy load. At full voltage I had a full 100w PEP on SSB.

<Marc W0KYZ>

By comparison, these are the measurements that I obtained from a new Yaesu FT-450AT late last year:

13.8V - 100W
 12.5V - 100W
 12.0V - 75W
 11.5V - 68W
 <VR2AX>

I looked up the % charge chart for my Trojan Deep Cycle battery:

100%	12.70V
80%	12.46V
75%	12.40V
50%	12.20V
45%	12.16V
25%	12.00V
10%	11.94V
5%	11.92V
Discharged @	11.90V

<Jack_son>

Receive standby current

Icom specs say 1.3A on receive squelched and 1.6A full volume.

I checked mine. I got 1.36A two minutes after power up with default settings on 2m FM. Full volume (painful) was 1.52A. I found I could save about 40mA by reducing "LCD Bright" to minimum (and still read the display) and another 40mA by turning off the switch backlighting. The readings were a little tough to validate because the fan is variable speed and can affect the readings by more than 100mA.

These numbers seem consistent with the published Icom specs. It's not exactly milliamps but it's still 500mA less than the IC-706MKIIG specs. <Scott N7SS>

How do I...?

How do I hook a monitor to my IC-7000?

The IC-7000 uses a 1/8" mono mini jack to provide composite video out. Any monitor, TV or VCR that supports composite video input (yellow RCA jack) can be used as a display. Although the 1/8" mini jack is small, it's not a standard video connector. Radio Shack offers a 6 foot cable (Catalog #: 42-2444) for only a few dollars that has a 1/8" mini plug to RCA plug and will connect the IC-7000 directly to a standard composite monitor/TV.

It is also possible to use an adapter to convert the 1/8" mini jack to an RCA to allow the use of a standard RCA cable. Rigid adapters should be used with caution because the jack can be pulled off the main board if too much torque is applied.

"To use with a standard computer monitor, it is necessary to convert the composite video to RGB video with a device like the [KWorld TV Box 1680ex](#).

I use this one and it works ok but the above is better: <http://www.aver.com/mpd/tvbox9.html>
<Steve Ellington, N4LQ>

How do I use a Bluetooth headset with my IC-7000?

"Works great. See link below from K7Sfn. <http://www.k7sfn.com/projects/bluetooth.html>"
<Dave, KI4KQ>

How do I connect more than one CI-V device to my IC-7000?

The Icom CI-V interface is a serial bus design. This allows more than one device to be connected to the radio CI-V interface (amplifier, antenna switch, SteppIR antenna, additional radios, etc.). "To connect these devices get a flexible adapter like the Radio Shack 42-2437 or even a three-way adapter like the Radio Shack 42-2458". <Doug Faunt, N6TQS>

How do I get better transmitted audio?

The IC-7000 was designed as a mobile radio and the microphone was intended to be used in high noise environments. Although the Heil microphones and W2IMY equalizers provide excellent audio, many people want to maintain the functionality of the stock microphone and get better audio without the expense of these options. AB5N has created a modification for the stock microphone at <http://www.7000mic.com/> that creates a "hotter" microphone and higher quality audio. There is also a microphone modification posted at <http://www.mods.dk/>.

The IC-7000 has two microphone jacks but the Icom manual specifically states that only one microphone should be used at a time. This is likely because both microphones would be hot at the same time. Some have suggested a mute switch (disabling the mike element) in the stock microphone. This would allow the stock microphone to be used as a "remote control" in one mike jack with a headset in the second mike jack.

How do I use my IC-7000 on 60m?

Page 40 of the IC-7000 manual provides information on 60m operation and is quoted below.

To assist you in operating the 5 MHz band correctly within the rules specified by the FCC, transmission is impossible on any 5 MHz band frequency other than the 5 frequencies indicated in the table below.

IC-7000 Display Frequency*	FCC Channel Center Frequency*
5.33050 MHz	5.33200 MHz
5.34650 MHz	5.34800 MHz
5.36650 MHz	5.36800 MHz
5.37150 MHz	5.37300 MHz
5.40350 MHz	5.40500 MHz

NOTE: We recommend that you store these frequencies, mode and filter settings into the memory channel for easy recall.

*The channel center frequencies that are specified by the FCC, show the center frequency of their passband. However, the IC-7000 displays carrier point frequency, so set 1.5 kHz below from FCC

channel center frequency.

How do I get full power output when transmitting?

The IC-7000 was designed to deliver full power output at 13.8 volts. This is the voltage provided by most power supplies and the alternator output of a vehicle. The voltage table at the beginning of this FAQ shows output as voltage drops. When using the radio from a battery it is necessary to use the largest possible power cabling and a battery voltage booster to maintain the 13.8 volts required for maximum output.

I use my IC7000 on CW almost exclusively, and I operate ONLY mobile. I use the N8XJK booster <http://stores.tgelectronics.org/> with no problems at all. For a while I used it with the RF sensing, but no longer do so... not because of any performance problems, but because when the engine is running I don't need the booster, and when in receive I don't hear any noise problems from the booster, so I decided to so away with the additional wiring needed to use the RF Sensing. <Dave- K9FN>

“I will ad that the MFJ-4416 voltage booster has helped greatly when the vehicle isn't running. This radio and many other mobiles do not Tx full output power on less than 13+ volts. So either get a battery voltage booster or keep the vehicle running.” <AE5MH>

How do I use my radio in VOX mode?

“Two things two check. You are in a voice mode and you have turned VOX on. I just tried it and it works with the stock 151 microphone. Be sure the word VOX shows up on your display.” <Steve Ellington N4LQ>

“Turn the VOX Gain up reasonably high, and turn the Anti-VOX as low as you can with out the speaker triggering the VOX. My 7000 works great with stock microphone in VOX mode.” <Dave - KI4KQ>

How do I access the CW/Voice memory keyer?

The CW and voice keyer options are accessible through the menu. When using the keyers via menu, it is not possible to access other features or the popular multimeter screen. There is a simple resistor network with switches shown in the manual to allow immediate access to the CW/voice memory keyer.

“I made the device in the photo for solve this problem using the circuit at the 135 Page. I use my 7k for contesting and expeditions so the voice message function is a powerful help but use it via the menus is complex. <http://www.netcommunity.com/ea1nt/7kbox.htm> <Luis EA1NT>

How do I use a Turbo Tuner and screwdriver antenna with an IC-7000

On the Turbo Tuner Web site, N2VZ is shipping Turbo Tuners setup for the 7000 AND the software update for Turbo Tuners that were programmed for 706, to make it a 7000 tuner. He will email you the update to flash your 706 Turbo Tuner thru the RS232 port on the Turbo Tuner.

<http://www.n2vz.com/>

<Kent KQ4KK>

How do I enter DTMF tones for Echolink/IRLP or repeater control?

The stock IC-7000 microphone has many functions but like the IC-706 family, it can't generate DTMF tones. There are two solutions offered by Icom. The first option is the same DTMF microphone used by the IC-706, the HM-154T.

There are also 4 DTMF memories of up to 24 digits described on page 67-68 of the IC-7000 manual. This allows recording command/control sequences in these memories. Set Menu Option 38 specifies which DTMF option appears when F-2 is pressed in the menu.

Can I use my IC-706 accessories with my IC-7000?

Most accessories from Icom and third parties will work directly with the IC-7000. There are a few exceptions. The Icom remote kit is different for the IC-7000. The body and head bracket are the same but the remote cable has 10 pins, rather than only 8 pins. The microphones are largely compatible but the IC-7000 does not have an audio output line in the microphone cable. This could effect some TNC cables and older Heil headsets. The later Heil headsets have a separate speaker plug. There have also been some compatibility issues with third-party tuners (LDG and Turbo Tuner) although ROM upgrades are generally available to address these issues.

Where do I find...?

DC Power connector

“New HF radios from Japan, introduced in the past 5 years operating on 12V DC, like the ICOM IC-7000, Kenwood TS-480, Yaesu FT-450, Yaesu FT-2000, and the new ICOM entry level radio all use the same connector, wired the same way.” <John Bee N1GNV – Quicksilver Radio>

Quicksilver Radio - <http://www.qsradio.com/DCpower.htm>

Tower Electronics - <http://www.pl-259.com/>

Powerwerx - <http://www.powerwerx.com/>

Wimo - http://wimo.de/cgi-bin/verteiler.pl?url=netzgeraete-zubehoer_d.html

Monitor

There are too many monitor options available from too many sources to list here. The IC-7000 provides composite video out. This can be run into most TV sets and VCRs with the appropriate cable (1/8" monaural mini plug to RCA plug).

Small monitors can often be found on eBay and any place that sells car audio/video. In-dash DVD players and many navigation systems include a composite video input. There has even been some discussion that a Toyota Prius instrument panel has an input that could be used for an IC-7000.

Icom uses a 7" Xenarc 700YV monitor in the display they use at hamfairs. This monitor is more than what is necessary for most users. The rated LCD brightness of 500 cd/m² and contrast ratio of 400:1 creates a nice image. These are the two most important numbers when determining the quality of an LCD display. Often these numbers are not available and the price is the only indication of the relative monitor quality.

CI-V computer interfaces for serial and USB

Icom sells the CT-17 interface, which offers 4 CI-V ports and a single DB-9 serial port. There are a number of less expensive options available on the market in both serial and USB. These are commonly found on eBay. Radio Shack also has some scanner programming cables that will work.

"I purchased the Radio Shack 20-047 USB Programming Cable & Driver Software today.(the number and description is right off their label)I followed their directions and connected the USB plug after installing the driver. It connects at 19,200 bps and has not given one sign of improper connection...This is faster and easier than the CT-17.I used a 20 foot stereo extension to get to the ICOM and used the stereo to mono adapter supplied with the interface to plug in at the radio end of the connection.18 hours later, I am sure this is the best way to go." <im2old2run>

Interfaces are also available from:

West Mountain Radio - <http://www.westmountainradio.com/RIGtalk.htm>

MFJ <http://www.mfjenterprises.com/Product.php?productid=MFJ-5383I>

Control software

The IC-7000 is similar to the other Icom HF radios and can use much of the same software written for the IC-706 family (although the radio address may need to be changed). More software is offering native IC-7000 support. One of the first and best is Ham Radio Deluxe (HRD) and is available for download at no cost from <http://www.ham-radio-deluxe.com/>.

Memory programming software

There are a number of packages specifically designed to program the memory channels in the IC-7000.

Rumtrol7k <http://www.dl2rum.de/rumsoft/RUMtrol7K.html>

IC7000BKT http://iz2bkt.altervista.org/ic7000bkt_en.htm

CI-V Cat.program/Memory Manager <http://www.tellina.nl/software/>

Radio Issues

The IC-7000 runs hot even on receive

There are reports of the IC-7000 running hot despite most of the radio body being cooler than the IC-706. There are three points in particular that can run warm; the display because of the backlight, the area behind the speaker where the DSP ICs are heat sinked and the actual heat sink on the back of the radio.

Here is a chart showing relative temperatures of various devices with color displays. The temperatures below were taken with an infrared thermometer after a 24 hour warm-up period at 71 degrees F with no transmit.

Icom IC-7000	91°F	33°C
Icom IC-2800	107°F	41°C
Sharp 15" TV/Monitor	85°F	29°C
G2G 5" TFT Portable Monitor	106°F	41°C
Initial 7" Portable DVD Player	85°F	29°C

The display runs about 91°F. The heatsink on the rear runs 99-103°F (in receive). The cooler areas on the back are 92-96°F. The temperature on the top ranges from 95-109°F. The area directly behind the speaker is the hottest at 109°F. This is directly over the silver box containing the DSP chips.

The thermometer on the multimeter display shows the rear heatsink temperature. The final output transistors use this heatsink.

Many users have installed fans over or behind the radio to increase the airflow over the chassis. Care must be taken with fans in dusty environments. There is also a fan modification published on <http://www.mods.dk>.

Strange behavior on transmit (shutting down, resetting, changing frequency, etc.)

This is most commonly a grounding/RFI issue. Make sure the radio and antenna are properly grounded. If the separation cable is being used, attempt to route it away from RF sources and be sure to use the screw to attach it to the radio.

Audio feedback during transmit

Check to make sure you don't have the "monitor" turned on. Usually, you just use the monitor when transmitting digital modes.

- Push SET button (AF gain control knob) upper left hand corner of radio.
- Go to "Set Mode" > OTH > Monitor. Set to OFF

<Brian, KC4UKR>

High frequency (8kHz) tone in audio

Very early models of the radio had a noticeable tone at 8kHz. This was not audible through the internal speaker because the internal speaker is "communications grade", meaning it has a frequency response limited to voice frequencies. It was also not audible when using Heil, David Clark and other

communications headphones or speakers. It was most obvious when using inexpensive “Walkman” style hifi headphones which are excellent at reproducing non-voice frequencies.

Icom addressed this within a few months after production began with some capacitor and grounding changes. This modification should be available at no charge for units in warranty.

Low level hiss in audio

Many radios have a small amount of hiss (white noise) when the volume is set to the minimum value. This hiss remains at a constant level as the volume is increased and is quickly overwhelmed by signal audio. The hiss is apparently internally generated. There is no known solution but some users insert attenuators in the audio line. Since the hiss is a fixed level, it will reduce the hiss level while allowing the signal level to be increased with additional AF gain.

This audio hiss is very low through the internal speaker because it is “communications grade”, meaning it has a frequency response limited to voice frequencies. Any external speaker or headphones should also be designed for communications work, rather than hi-fi, so as to minimize this issue.

S-meter reads low

The IC-7000 S-meter is very accurate but as a mobile unit is calibrated to read accurately with the preamp enabled.

Changing the transmit audio bandwidth results in poor transmit audio

The Icom IC-7000 supports changing the transmit audio bandwidth. There are three predefined settings which can be modified. Because it appears the transmit equalization feature was cut, there is no way to rebalance the audio as the bandwidth is narrowed. This makes the audio quality very poor at narrow bandwidths. If DX-quality narrow audio is desired, the best solution is a good DX microphone or an external equalizer like those from W2IHY.