

(1) CONNECTED to RS0ISS-1 - 02.07.117 13:41:53

Logged on to RS0ISS's Personal Message System

on board the International Space Station

SP RS0ISS

CMD(B/H/J/K/KM/L/M/R/S/SB/SP/ST/SR/V/?)>

Subject:

Hello Crew !

Message:

Hello Crew

I am ON4CKT Rudy

QTH BELGIUM JO21ba

Please message back in this PMS.

Greetings 73's ON4CKT Rudy

Message saved as Msg # 437

CMD(B/H/J/K/KM/L/M/R/S/SB/SP/ST/SR/V/?)>

I

Msg #	Stat	Date	Time To	From	@ BBS	Subject
437	P	00/00/00	00:02	RS0ISS ON4CKT		Hello Crew !
436	P	00/00/00	00:29	KK6QMS DJ6TB		QSL msg #418
435	P	00/00/00	00:32	LU8FJH LU1WRC		contacto via iss
434	P	00/00/00	00:25	KK6QMS DJ6TB		QSL your Mail
433	B	00/00/00	00:51	RS0ISS LU1KCQ		Saludos desde Tucuman!
432	B	00/00/00	00:17	ASK CM5ADR		hello
431	P	00/00/00	00:42	I6IBE LU1WRC		re saludos

428 PR 00/00/00 00:04 ALL DJ6TB Greetings to all via ISS
425 PR 00/00/00 00:13 KK6QMS DJ6TB QSL on you mail vi ISS
421 PR 00/00/00 00:55 ALL CM8NMN TO ALL FROM CUBA!

41885 Bytes free

Next message Number 438

Mailbox selected: 0

CMD(B/H/J/K/KM/L/M/R/S/SB/SP/ST/SR/V/?)>

H

B(ye) B [CR] disconnects you from PMS.

H(elp) H [CR] or ? [CR] displays this help file.

J(log) J [CR] displays a list of callsigns heard (optional date/time)

K(ill) K n [CR] deletes message number n (only to/from your callsign).

KM(ine) KM[CR] deletes all READ messages addressed to your call sign.

L(ist) L [CR] lists the 10 latest messages.

M(ine) M [CR] lists the 10 latest messages to/from your callsign.

R(ead) R n [CR] reads message number n.

S(end) S (callsign) [CR] begins a message addressed to (callsign).

SB Sends Bulletin

SP Sends Personal

ST Sends Traffic

Subject: ending with [CR].

Text: End each line with [CR]. End message by

typing /ex [CR] or CTRL-Z [CR]

at the beginning of a new line.

SR(eply) SR n[CR] Sends a reply to message n prompting only for text.

V(ersion) V [CR] displays the software version of the PMS system.

CMD(B/H/J/K/KM/L/M/R/S/SB/SP/ST/SR/V/?)>

B

(1) LINK FAILURE with RSOISS-1 - 02.07.117 13:50:29