

## CONTINUITY CHECKLIST -- DISPLAY

	From	To		
<input type="checkbox"/>	P2-1,2	P3-1	GND	Display Power and Control
<input type="checkbox"/>	P2-3,4	P3-3	5V	Display Power and Control
<input type="checkbox"/>	P2-5,6	P3-37	3.3V	Display Power and Control
<input type="checkbox"/>	P2-27/PD7	P3-29	TFT-CS	Display Power and Control
<input type="checkbox"/>	P2-29/PD5	P3-9	TFT-WR	Display Power and Control
<input type="checkbox"/>	P2-32/PD4	P3-11	TFT-RD	Display Power and Control
<input type="checkbox"/>	P1-43/PD11	P3-7	TFT-RS	Display Power and Control
<hr/>				
<input type="checkbox"/>	P1-46/PD14	P3-2	D0	Display Data
<input type="checkbox"/>	P1-47/PD15	P3-4	D1	Display Data
<input type="checkbox"/>	P2-36/PD0	P3-6	D2	Display Data
<input type="checkbox"/>	P2-33/PD1	P3-8	D3	Display Data
<input type="checkbox"/>	P1-25/PE7	P3-10	D4	Display Data
<input type="checkbox"/>	P1-26/PE8	P3-12	D5	Display Data
<input type="checkbox"/>	P1-27/PE9	P3-14	D6	Display Data
<input type="checkbox"/>	P1-28/PE10	P3-16	D7	Display Data
<input type="checkbox"/>	P1-29/PE11	P3-13	D8	Display Data
<input type="checkbox"/>	P1-30/PE12	P3-15	D9	Display Data
<input type="checkbox"/>	P1-31/PE13	P3-17	D10	Display Data
<input type="checkbox"/>	P1-32/PE14	P3-19	D11	Display Data
<input type="checkbox"/>	P1-33/PE15	P3-21	D12	Display Data
<input type="checkbox"/>	P1-40/PD8	P3-23	D13	Display Data
<input type="checkbox"/>	P1-41/PD9	P3-25	D14	Display Data
<input type="checkbox"/>	P1-42/PD10	P3-27	D15	Display Data
<hr/>				
<input type="checkbox"/>	P1-36/PB12	P3-20	TP-CS	Touch Panel Control
<input type="checkbox"/>	P1-37/PB13	P3-18	TP-CLK	Touch Panel Control
<input type="checkbox"/>	P1-38/PB14	P3-26	TP-MISO	Touch Panel Control
<input type="checkbox"/>	P1-39/PB15	P3-22	TP-MOSI	Touch Panel Control
<input type="checkbox"/>	P2-30/PD6	P3-28	TP-IRQ	Touch Panel Control